

## 3M™ ESPE™ F2000 Compomer Restorative Adper™ Bond Adhesive System

### Indication:

- Crown buildup

### Preparation:

- Isolate the tooth.
- Remove caries.
- Place retention if multiple cusps are missing.
- Place appropriate matrix if desired.
- The blue shade will provide contrasting color to tooth structure.

### Etch:

- Apply Scotchbond™ Etchant to enamel and dentin. Wait 15 seconds.
- Rinse.
- **Blot excess water leaving tooth moist.\***



### Bond:

- Using a fully saturated brush tip for each coat, apply **2 consecutive coats** of Adper™ Single Bond Adhesive to enamel and dentin.
- **Dry gently** for 2-5 seconds.
- Light cure the adhesive for 10 seconds.



## 3M™ ESPE™ F2000 Compomer Restorative Adper™ Bond Adhesive System



### Place Compomer:

- F2000 Compomer will not self-cure.
- Place F2000 compomer incrementally.
- Light-cure each increment for 40 seconds.



### Prepare Crown:

- The F2000 compomer core buildup can be prepared immediately after light curing.



### Notes:

- The compomer core is compatible with commonly used impression materials.
- The compomer core should be kept wet with saliva or lubricated to prevent bonding to chemical-cure provisionals.
- Commonly used temporary luting cements will not bond to the compomer core.